

# Maintaining Your Gear

Always ensure that all the screws are tight. If you develop play, loosen the 4 screws on this end of the unit. Push inward on the end-piece that the screws are threaded into, with the gear in the down position. Then re-tighten the screws. This will re-set tolerances to manufactured specs. The gear will act as brand new!

